



ALTOS
COMPUTING

R380 F5



USER'S MANUAL
Revision 1.0

Manual Revision 1.0

Release Date: April 30, 2021

mk

Unless you request and receive written permission from Altos Computer, Inc., you may not copy any part of this document. Information in this document is subject to change without notice. Other products and companies referred to herein are trademarks or registered trademarks of their respective companies or mark holders.

Preface

About this Manual

This manual is written for professional system integrators and PC technicians. It provides information for the installation and use of the server. Installation and maintenance should be performed by experienced technicians only.

Warnings

Special attention should be given to the following symbols used in this manual.



Warning! Indicates important information given to prevent equipment/property damage or personal injury.



Warning! Indicates high voltage may be encountered when performing a procedure.

Chapter 1

Introduction

1.1 Overview

This chapter provides a brief outline of the functions and features of the R380 F5. The following provides an overview of the specifications and capabilities.

| System Overview | |
|--------------------------|--|
| Motherboard | |
| Chassis | 829U3TS-R1K22P-T |
| Processor Support | Dual P+ (LGA4189) sockets 3rd Gen Intel Xeon Scalable |
| Memory | 32 DIMM slots, DDR4 RDIMM/LRDIMM or Intel Optane PMem 200 Series* (up to 8TB for DDR4, or up to 8TB of PMem and 4TB DDR4) Up to 3200MHz; size up to 256GB * Note: PMem 200 Series are supported on 3rd gen Intel Xeon Scalable Platinum, Gold and selected Silver processors. |
| Drive Support | Twelve 3.5" SATA/SAS/NVMe hybrid drive bays Two SuperDOM (disk on modules) |
| Expansion Slots | Eight PCIe 4.0: Five x8 full-height, 10.5" One x16 full-height, 10.5" One x16 low profile One internal x8 low-profile |
| I/O Ports | LAN ports depend on Ultra Riser option One VGA ports (rear) One serial port (rear) Two USB 3.0 ports (rear) |
| System Cooling | Four 8-cm heavy duty fans with Optimal Fan Speed Control Air Shroud, CPU heatsinks |
| Power | 1600W redundant 80Plus Titanium level modules; (<i>optional</i>) 1300W DC power supplies Optional 2000W modules |
| Form Factor | 2U rackmount; (WxHxD) 17.2 x 3.5 x 27.6 in. (437 x 89 x 706 mm) |

Configuration Options

Ultra Riser Cards

Ultra Riser cards provide network connections and other capabilities. The customer must choose one when purchasing the system.

| Ultra Riser Networking Options | | |
|--------------------------------|-------------------|---|
| LAN Ports | Part Number | Description |
| No NIC | AOC-2UR668G4 | Two PCIe 4.0 x16 and PCIe 4.0x8 (in x16, internal) |
| Two 10GBaseT | AOC-2UR68G4-i2XT | Two RJ45, Intel X710-AT2, PCIe 4.0 x8 (in x16, Internal), PCIe 4.0 x8 (in x16), PCIe 4.0 x16 |
| Four 10GBaseT (two SFP+) | AOC-2UR68G4-i4XTS | Two RJ45 and two SFP+, Intel X710-TM4, PCIe 4.0 x8 (in x16, Internal), PCIe4.0 x8 (in x16), PCIe 4.0 x16 |
| Two 25GbE | AOC-2UR68G4-m2TS | Two 25GbE, two SFP28, Mellanox ConnectX-6, PCIe 4.0 x8 (in x16, Internal), PCIe 4.0 x8 (in x16), PCIe 4.0 x16 |

WIO Riser Cards

Several customer choices are available for other riser cards. See the [Expansion Slots and Riser Cards](#) section in this chapter for details.

Storage Protocols

The storage drive bays can support SATA, SAS, and NVMe in any combination. To enable SAS and NVMe, additional hardware is required. Once the supporting hardware is installed for a selection of bays, drives of any storage protocol type can be inserted.

SATA – The default configuration supports up to twelve SATA drives.

SAS – An add-on controller card and cables can support up to twelve SAS drives.

NVMe – The motherboard supports up to ten NVMe drives. A retimer card is required to add support for an additional two NVMe drives. Additional cables are required.

Power Supply Options

| Power Supply Module Options | | |
|-----------------------------|------------------------|----------------|
| Watts | Part Number | 80Plus Level |
| 1600 | PWS-1K62A-1R (default) | Titanium |
| 2000 | PWS-2K08A-1R PWS- | Titanium |
| 1300 DC | 1K30D-1R | Not applicable |

1.2 System Features

The following views of the system display the main features. Refer to [Appendix B](#) for additional specifications.

Front View

Service/Asset Tag
with BMC Password



Control Panel

Figure 1-1. Front View

| Logical Storage Drive Numbers | |
|-------------------------------|--|
| Item | Description |
| 0-5 | 3.5" hot-swap SAS3*/SATA/NVMe* drive bays (NVMe from CPU1) |
| 6-11 | 3.5" hot-swap SAS3*/SATA/NVMe* drive bays (NVMe from CPU2) |

* SAS3 and NVMe support requires with additional parts

Drive Carrier Indicators

Each drive carrier has two LED indicators: an activity indicator and a status indicator. For RAID configurations using a controller, the meaning of the status indicator is described in the table below. For OS RAID or non-RAID configurations, some LED indications are not supported, such as hot spare. For VROC configurations, refer to the [VROC section](#) in this manual.

| Drive Carrier LED Indicators | | | |
|------------------------------|-------|------------------|----------------------------------|
| | Color | Blinking Pattern | Behavior for Device |
| Activity | Blue | Solid On | Idle SAS or NVMe drive installed |
| LED | Blue | Blinking | I/O activity |
| | Off | | Idle SATA or no drive |

| Drive Carrier LED Indicators | | | |
|------------------------------|-------|---|---------------------------------------|
| | Color | Blinking Pattern | Behavior for Device |
| Status LED | Red | Solid On | Failure of drive with RSTe support |
| | Red | Blinking at 1 Hz | Rebuild drive with RSTe support |
| | Red | Blinking at 4 Hz | Identify drive with RSTe support |
| | Red | Blinking with two blinks and one stop at 1 Hz | Hot spare for drive with RSTe support |
| | Red | On for five seconds, then off | Power on for drive with RSTe support |
| | Amber | Blinking | Safe to remove NVMe drive |
| | Green | Solid on | Ejecting an NVMe drive |

Control Panel




Figure 1-2. Control Panel

| Control Panel Features | |
|--------------------------|--|
| Feature | Description |
| Power button | The main power switch applies or removes primary power from the power supply to the server but maintains standby power. Hold for four seconds to force a shut-down. |
| UID button/LED BMC reset | The unit identification (UID) button turns on or off the blue light function of the Information LED and a blue LED on the rear of the chassis. This button can also be used to reset the BMC . |
| Power LED | Steady on – Power on Blinking at 4Hz – Checking BIOS/BMC integrity Blinking at 4Hz and "i" LED is blue – BIOS firmware updating Two blinks at 4Hz, one pause 2hz and "i" LED blue – BMC firmware updating Blinking at 1Hz and "i" LED red – Fault detected |
| HDD LED NIC | Indicates activity on the storage drives when flashing. |
| LED Power Fail | Indicates network activity on LANs when flashing. |
| LED Information | Indicates a power supply module has failed. |
| LED | Alerts operator to several states, as noted in the table below |

| Information LED | |
|--|--|
| Color, Status | Description |
| Red, solid | An overheat condition has occurred. |
| Red, blinking at 1Hz | Fan failure, check for an inoperative fan. |
| Red, blinking at 0.25Hz | Power failure, check for a non-operational power supply. |
| Red, solid, with Power LED blinking green | Fault detected |
| Blue and red, blinking at 10 Hz | Recovery mode |
| Blue, solid | UID has been activated locally to locate the server in a rack environment. |
| Blue, blinking at 1Hz | UID has been activated using the BMC to locate the server in a rack environment. |
| Blue, blinking at 2Hz | BMC is resetting |
| Blue, blinking at 4Hz | BMC is setting factory defaults |
| Blue, blinking at 10Hz with Power LED blinking green | BMC/BIOS firmware is updating |

Rear View




Figure 1-3. System: Rear View

| System Features: Rear | |
|-----------------------|--|
| Feature | Description |
| Power Supplies | Two redundant power supply modules, PWS1 on the left, PWS2 on the right |
| 0 | LAN ports; specifications depend on your Ultra riser card option |
| 1 to 8 | Expansion card slots; see the next page for details |
| USB | Two USB 3.0 ports |
| BMC LAN | BMC LAN port; for indicator details, see BMC LAN LEDs |
| UID LED/ BMC Reset | UID button and BMC reset button (see Control panel description) |
| COM | Serial port |
| VGA | Video port |

Power Supply Indicator

LEDs on the power supplies indicate the status of the module.

| Power Supply Indicator | |
|------------------------|--|
| LED Color and State | Power Supply Condition |
| Solid Green | Indicates that the power supply is on |
| Blinking Green | Indicates that the power supply is plugged in and turned off by the system. |
| Blinking Amber | Indicates that the power supply has a warning condition and continues to operate. |
| Solid Amber | Indicates that the power supply is plugged in, and is in an abnormal state. The system might need service. Please contact ALtos technical support. |
| Off | No AC power to modules |

Expansion Slots and Riser Cards

This system offers options for riser cards that provide custom PCIe capabilities—one Ultra Riser card, one right-facing WIO riser card, and one left-facing WIO card.

| PCIe Slots per Riser Card | | | |
|---------------------------|---|------|---------------------------------|
| Riser Card | Part Number | Slot | Description (all PCIe 4.0) |
| Ultra Riser card | AOC-2UR668G4 | 1 | x16 FH, 10.5"L (CPU2) |
| | | 2 | x16 FH, 10.5"L (CPU2) |
| | | 3 | x8 (in x16), Internal LP (CPU1) |
| | AOC-2UR68G4-i2XT AOC-2UR68G4-i4XTS AOC-2UR68G4-m2TS | 1 | x16 FH, 10.5"L (CPU2) |
| | | 2 | x8 (in x16) FH, 10.5"L (CPU2) |
| | | 3 | x8 (in x16) Internal LP (CPU2) |
| Right-facing | RSC-WR-6 | 4 | x16 low profile (CPU1) |
| Left-facing | RSC-W2-8888G4 | 5 | x8 FH, 10.5"L (CPU2) |
| | | 6 | x8 FH, 10.5"L (CPU2) |
| | | 7 | x8 FH, 10.5"L (CPU1) |
| | | 8 | x8 FH, 10.5"L (CPU1) |
| | RSC-W2-688G4 | 5 | x16 FH, 10.5"L (CPU2) |
| | | 7 | x8 (in x16) FH, 10.5"L (CPU1) |
| | | 8 | x8 (in x16) FH, 10.5"L (CPU1) |
| | RSC-W2-66G4 | 5 | x16 FH, 10.5" (CPU2) |
| | | 7 | x16 FH, 10.5" (CPU1) |

One riser card slot may be used for a controller card that supports SAS. Up to one riser card slot may be used for a retimer card that supports NVMe.

LAN Speed Indicator

LAN ports are provided by the [Ultra Riser cards](#). One LED indicates the network speed.

| LAN LED (Speed Indicator) | | |
|---------------------------|---------|---------|
| Color | 10GbE | 25GbE |
| Green | 10 Gb/s | 25 Gb/s |
| Amber | 1 Gb/s | 10 Gb/s |

Top View




Figure 1-4. System: Top View

| System Features: Top | |
|----------------------|--|
| Feature | Description |
| Power Supply | Dual redundant modules; see options on previous page |
| SuperDOM ports | Disk-on-Module port allows for flash cards to be mounted directly on the motherboard |
| DIMM slots | Dual in-line memory module (DIMMs) slots |
| Processors | Dual Intel Xeon Scalable Processors with heatsinks, SNK-P0078P |
| System fans | Four 8-cm heavy duty PWM fans, FAN-0209L4 |

1.3 System Architecture

This section shows the locations of the system electrical components, and a block diagram of the overall system.

Main Components




Figure 1-5. Main Component Locations

System Block Diagram

The block diagram below shows the connections and relationships between the subsystems and major components of the overall system.




Figure 1-6. System Block Diagram

1.4 Motherboard Layout

Below is a layout of the X12DPU-6 motherboard with jumper, connector and LED locations shown. See the table on the following page for descriptions. For detailed descriptions, pinout information and jumper settings,




Figure 1-7. Motherboard Layout

Quick Reference

| Jumper | Description | Default Setting |
|--------|--------------------------------|------------------------|
| JBT1 | Clear CMOS | Open (Normal) |
| JUID | UID Enable/System Reset Jumper | Pins 1-2 (UID Enabled) |

| Connector | Description |
|-------------------------------|---|
| BT1 | Onboard CMOS battery |
| COM1 | Backplane COM port |
| FAN1 ~ FAN8 | CPU/System fan headers |
| FP1 | FFC (Flat Flexible Cable) connector |
| BMC_LAN | Dedicated BMC LAN port (JLAN1) |
| I-SATA 0~3, I-SATA 4~7 | Intel PCH SATA 3.0 ports |
| S-SATA 0~3, S-SATA 4/S-SATA 5 | S-SATA 0~3, S-SATA 4/S-SATA 5 supported by Intel PCH (S-SATA 4/5: Powered SATA connectors (with power pins built-in to be used of SuperDOM devices) |
| JF1 | Front Control Panel header |
| JF3 | Front Panel sensor |
| JF4 | BMC I2C Signal for 24 NVMe BPN (Backplane) |
| JIPMB1 | 4-pin BMC external I2C header (for a BMC card) |
| JL1 | Chassis intrusion header |
| JNCSI | NC-SI (Network Controller Sideband Interface) connector |
| JNVl2C3/JNVl2C4 | NVMe I2C headers (JNVl2C3: for VPP#1/JNVl2C4: for VPP#2) |
| JGPW1/JGPW2/JGPW3/JGPW4 | GPU 8-pin power connectors (power connectors for GPU use) |
| JPW1/JPW2/JPW3/JPW4 | Backplane 8-pin power connectors (for backplane devices) |
| JUIDB | UID LED/BMC Reset switch |
| JVGA2 | Front accessible VGA connection header (optional) |
| PSU1/PSU2 | Power Supply Unit #1/Power Supply Unit #2 for system use |
| JSD1/JSD2 | SATA DOM (Disk_On_Module) power connectors |
| JTPM1 | Trusted Platform Module connector |
| P1-NVMe1/3/4/5/6 | PCIe 4.0 x8 NVMe ports |
| P2-NVMe7/8/9/10 | PCIe 4.0 x8 NVMe ports |
| SXB1A/SXB1B/SXB1C | PCIe 4.0 (x16 + x16) Left riser card slot supported by CPU1/CPU2 |
| SXB2 | PCIe 4.0 x16 slot supported by CPU1 |
| SXB3A/SXB3B/SXB3C | PCIe 4.0 (x16 + x16 + x8) Ultra riser slot supported by CPU2 |
| T-SGPIO3 | Serial_Link General-Purpose I/O connection header (for S-SATA 4/5 SuperDOM support) |
| USB0/1 (3.0) | Rear I/O USB 3.0 ports |
| USB3/4 (3.0) | Front accessible USB header with two USB 3.0 connections |
| VGA | Backplane VGA port |
| VROC (JRK1) | Intel VROC Key Header for NVMe RAID |

| LED | Description | State: Status |
|-----|--------------|---|
| JF2 | LAN LED | Ethernet LAN LED Indicators (Blink: Active) |
| LE2 | Power_on LED | System Power LED: (On: System Power on) |

| LED | Description | State: Status |
|-------|--------------------------------|-----------------------------|
| LEDM1 | BMC Heartbeat LED | Blinking Green: BMC Normal |
| LED1 | Rear UID (Unit Identifier) LED | Solid Blue: Unit Identified |

Motherboard Block Diagram




Figure 1-8. Motherboard Block Diagram

Chapter 2

Server Installation

2.1 Overview

This chapter provides advice and instructions for mounting your system in a server rack. If your system is not already fully integrated with processors, system memory etc., refer to [Chapter 3](#) for details on installing those specific components.

Caution: Electrostatic Discharge (ESD) can damage electronic components. To prevent such damage to PCBs (printed circuit boards), it is important to use a grounded wrist strap, handle all PCBs by their edges and keep them in anti-static bags when not in use.

2.2 Unpacking the System

Inspect the box in which the system was shipped, and note if it was damaged. If any equipment appears damaged, file a claim with the carrier.

Decide on a suitable location for the rack unit that will hold the server. It should be situated in a clean, dust-free area that is well ventilated. Avoid areas where heat, electrical noise and electromagnetic fields are generated. It will also require a grounded AC power outlet nearby. Be sure to read the precautions and considerations noted in [Appendix A](#).

2.3 Preparing for Setup

The box in which the system was shipped should include the rackmount hardware needed to install it into the rack. Please read this section in its entirety before you begin the installation.

Choosing a Setup Location

- The system should be situated in a clean, dust-free area that is well ventilated. Avoid areas where heat, electrical noise and electromagnetic fields are generated.
 - Leave enough clearance in front of the rack so that you can open the front door completely (~25 inches) and approximately 30 inches of clearance in the back of the rack to allow sufficient space for airflow and access when servicing.
 - This product should be installed only in a Restricted Access Location (dedicated equipment rooms, service closets, etc.).
-

- This product is not suitable for use with visual display workplace devices according to §2 of the German Ordinance for Work with Visual Display Units.

Rack Precautions

- Ensure that the leveling jacks on the bottom of the rack are extended to the floor so that the full weight of the rack rests on them.
- In single rack installations, stabilizers should be attached to the rack. In multiple rack installations, the racks should be coupled together.
- Always make sure the rack is stable before extending a server or other component from the rack.
- You should extend only one server or component at a time - extending two or more simultaneously may cause the rack to become unstable.
- Do not use a two-post "telco" type rack for 2U or larger servers.

Server Precautions

- Review the electrical and general safety precautions in [Appendix A](#).
- Determine the placement of each component in the rack *before* you install the rails.
- Install the heaviest server components at the bottom of the rack first and then work your way up.
- Use a regulating uninterruptible power supply (UPS) to protect the server from power surges and voltage spikes and to keep your system operating in case of a power failure.
- Allow any drives and power supply modules to cool before touching them.
- When not servicing, always keep the front door of the rack and all covers/panels on the servers closed to maintain proper cooling.

Rack Mounting Considerations

Ambient Operating Temperature

If installed in a closed or multi-unit rack assembly, the ambient operating temperature of the rack environment may be greater than the room's ambient temperature. Therefore, consideration should be given to installing the equipment in an environment compatible with the manufacturer's maximum rated ambient temperature (TMRA).

Airflow

Equipment should be mounted into a rack so that the amount of airflow required for safe operation is not compromised.

Mechanical Loading

Equipment should be mounted into a rack so that a hazardous condition does not arise due to uneven mechanical loading.

Circuit Overloading

Consideration should be given to the connection of the equipment to the power supply circuitry and the effect that any possible overloading of circuits might have on overcurrent protection and power supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.

Reliable Ground

A reliable ground must be maintained at all times. To ensure this, the rack itself should be grounded. Particular attention should be given to power supply connections other than the direct connections to the branch circuit (i.e. the use of power strips, etc.).



To prevent bodily injury when mounting or servicing this unit in a rack, you must take special precautions to ensure that the system remains stable. The following guidelines are provided to ensure your safety:

- This unit should be mounted at the bottom of the rack if it is the only unit in the rack.
 - When mounting this unit in a partially filled rack, load the rack from the bottom to the top with the heaviest component at the bottom of the rack.
 - If the rack is provided with stabilizing devices, install the stabilizers before mounting or servicing the unit in the rack.
 - Slide rail mounted equipment is not to be used as a shelf or a work space.
-

2.4 Installing the Rails

There are a variety of rack units on the market, which may require a slightly different assembly procedure. This rail set fits a rack between 26.8" and 36.4" deep.

The following is a basic guideline for installing the system into a rack with the rack mounting hardware provided. You should also refer to the installation instructions that came with the specific rack you are using.

Identifying the Rails

The chassis package includes two rail assemblies. Each assembly consists of three sections: An inner rail that secures directly to the chassis, an outer rail that secures to the rack, and a middle rail which extends from the outer rail. These assemblies are specifically designed for the left and right side of the chassis and labeled.




Figure 2-1. Identifying the Outer Rail, Middle Rail and Inner Rail
(Left Rail Assembly Shown)

Releasing the Inner Rail

Each inner rail has a locking latch. This latch prevents the server from coming completely out of the rack when the chassis is pulled out for servicing.

To mount the rail onto the chassis, first release the inner rail from the outer rails.

1. Pull the inner rail out of the outer rail until it is fully extended as illustrated below.
2. Press the locking tab down to release the inner rail.
3. Pull the inner rail all the way out.




Figure 2-2. Extending and Releasing the Inner Rail

Installing the Inner Rails on the Chassis

Installing the Inner Rails

1. Identify the left and right inner rails. They are labeled.
2. Place the inner rail firmly against the side of the chassis, aligning the hooks on the side of the chassis with the holes in the inner rail.
3. Slide the inner rail forward toward the front of the chassis until the quick release bracket snaps into place, securing the rail to the chassis.
4. Optionally, you can further secure the inner rail to the chassis with screws.




Figure 2-2. Installing the Inner Rails




Figure 2-3. Inner Rails Installed on the Chassis

Installing the Outer Rails onto the Rack

Each end of the assembled outer rail includes a bracket with hooks and square, spring-loaded pegs to fit into the square holes in your rack.

Installing the Outer Rail

1. Press upward on the locking tab at the rear end of the middle rail.
2. Push the middle rail back into the outer rail.
3. Hang the hooks on the front of the outer rail onto the square holes on the front of the rack. If desired, use screws to secure the outer rails to the rack.
4. Pull out the rear of the outer rail, adjusting the length until it just fits within the posts of the rack.
5. Hang the hooks of the rear section of the outer rail onto the square holes on the rear of the rack. Take care that the proper holes are used so the rails are level. If desired, use screws to secure the rear of the outer rail to the rear of the rack.




Figure 2-4. Extending and Mounting the Outer Rails

Note: The figure above is for illustrative purposes only. Always install servers at the bottom of the rack first.



Stability hazard. The rack stabilizing mechanism must be in place, or the rack must be bolted to the floor before you slide the unit out for servicing. Failure to stabilize the rack can cause the rack to tip over.



Warning: Do not pick up the server with the front handles. They are designed to pull the system from a rack only.

2.5 Installing the Chassis into a Rack

Once rails are attached to the chassis and the rack, you can install the server.



Warning: Mounting the system into the rack requires at least two people to support the chassis during installation. Please follow safety recommendations printed on the rails.

Installing the Chassis into a Rack

1. Extend the outer rails as illustrated.
2. Align the inner rails of the chassis with the outer rails on the rack.
3. Slide the inner rails into the outer rails, keeping the pressure even on both sides. When the chassis has been pushed completely into the rack, it should click into the locked position.
4. Optional screws may be used to hold the front of the chassis to the rack.




Figure 2-5. Installing the Server into the Rack

Note: Keep the ball bearing shuttle locked at the front of the middle rail during installation.

Note: Figure is for illustrative purposes only. Always install servers to the bottom of a rack first.

Removing the Chassis from the Rack

Caution! It is dangerous for a single person to off-load the heavy chassis from the rack without assistance. Be sure to have sufficient assistance supporting the chassis when removing it from the rack. Use a lift.

1. If necessary, loosen the thumb screws on the front of the chassis that hold it in the rack.
2. Pull the chassis forward out the front of the rack until it stops.
3. Press the release latches on each of the inner rails downward simultaneously and continue to pull the chassis forward and out of the rack.




Figure 2-6. Removing the Chassis From the Rack

Chapter 3

Maintenance and Component Installation

This chapter provides instructions on installing and replacing main system components. To prevent compatibility issues, only use components that match the specifications and/or part numbers given.

Installation or replacement of most components require that power first be removed from the system. Please follow the procedures given in each section.

3.1 Removing Power

Use the following procedure to ensure that power has been removed from the system. This step is necessary when removing or installing non hot-swap components or when replacing a non-redundant power supply.

1. Use the operating system to power down the system.
2. After the system has completely shut-down, disconnect the AC power cord(s) from the power strip or outlet. (If your system has more than one power supply, remove the AC power cords from all power supply modules.)
3. Disconnect the power cord(s) from the power supply module(s).

3.2 Accessing the System

A removable top cover allows access to the inside of the chassis.

Removing the Top Cover

1. Remove the two screws on each side of the cover, which secure the cover to the chassis. These two screws are optional and will not impact functionality if they are not installed.
2. Press the two release buttons and slide the cover toward the rear.
3. Lift the top cover up.

Check that all ventilation openings on the top cover and the top of the chassis are clear and unobstructed.

Caution: Except for short periods of time, do not operate the server without the cover in place. The chassis cover must be in place to allow for proper airflow and to prevent overheating.




Figure 3-1. Removing the Chassis Cover

3.3 Processor and Heatsink Installation

The processor (CPU) and processor carrier should be assembled together first to form the processor carrier assembly. This will be attached to the heatsink to form the processor heatsink module (PHM) before being installed onto the CPU socket.


Notes:

- Use ESD protection.
 - Unplug the AC power cord from all power supplies.
 - Check that the plastic protective cover is on the CPU socket and that none of the socket pins are bent. If they are, contact your retailer.
 - When handling the processor, avoid touching or placing direct pressure on the land grid array (gold contacts).
 - Improper installation or socket misalignment can cause serious damage to the processor or the socket and may require manufacturer repairs.
 - Thermal grease is pre-applied on new heatsinks. No additional thermal grease is needed.
 - Refer to the [ALtos website](#) for updates on processor support.
 - Graphics in this manual are for illustration only. Your components may look different.
-


The Processor Carrier Assembly

The processor carrier assembly is comprised of the processor and the processor carrier.


1. Hold the processor with the land grid array (LGA, gold contacts) facing down. Locate the gold triangle at the corner of the processor and the corresponding hollowed triangle on the processor carrier as shown below. These triangles indicate the location of pin 1.




2. Turn the processor over (with the gold LGA up). Locate the CPU keys on the processor and the four latches on the carrier as shown below.




3. Locate the lever on the carrier and, if necessary, press it down as shown below.



4. Align the CPU keys on the processor (A & B) with those on the carrier (a & b) as shown below.



5. Carefully place one end of the processor under latch 1 on the carrier, and then press the other end down until it snaps into latch 2 and is properly seated on the carrier.




The Processor Heatsink Module (PHM)

After creating the processor carrier assembly, mount the heatsink onto the carrier assembly to form the processor heatsink module (PHM).

Note: If this is a new heatsink, the thermal grease has been pre-applied. Otherwise, apply the proper amount of thermal grease to the underside of the heatsink.


1. Turn the heatsink over with the thermal grease facing up. Note the two triangle cutouts (A, B) located at the diagonal corners of the heatsink as shown in the drawing below.
2. On the processor carrier assembly, find pin 1, as noted by the triangles. Hold the processor carrier assembly over so that the gold LGA is facing up.
3. Align clip "a" (pin 1) on the carrier assembly with the triangular cutout A on the heatsink and b, c, d on the carrier assembly with B, C, D on the heatsink.
4. Push the carrier assembly onto the heatsink, making sure that all four clips on each corner are properly secured.




Installing the PHM into the CPU Socket

1. Remove the plastic protective cover from the CPU socket. Gently squeeze the grip tabs then pull the cover off.


CPU Socket with Plastic Protective Cover




2. Locate four threaded fasteners (a, b, c, d) on the CPU socket.




3. Locate four PEEK nuts (A, B, C, D) and four rotating wires (1, 2, 3, 4) on the heatsink as shown below.



4. Check that the rotating wires (1, 2, 3, 4) are in the unlatched position as shown.




5. Align nut A (next to the triangles and pin 1) on the heatsink with threaded fastener "a" on the CPU socket. Also align nuts B, C, D on the heatsink with threaded fasteners b, c, d on the CPU socket.
6. Gently place the heatsink on the CPU socket, making sure that each nut is properly aligned with its corresponding threaded fastener.




a, b, c, d:
Threaded Fastener on the CPU socket

7. Press all four rotating wires outward to latch the PHM onto the CPU socket.




8. With a t30-bit screwdriver, tighten all PEEK nuts in the sequence of A, B, C, and D with even pressure not greater than 12 lbf-in.




Removing the PHM from the CPU Socket

Be sure the system is shut down and all AC power cords are unplugged.


1. Use a t30-bit screwdriver to loosen the four PEEK nuts on the heatsink in the sequence of A, B, C, and D.



2. Press the four rotating wires inward to unlatch the PHM as shown below.




3. Gently lift the PHM upward to remove it from the CPU socket.



Removing the Processor Carrier Assembly from the PHM


Detach the four plastic clips (a, b, c, d) on the processor carrier assembly from the four corners of the heatsink (A, B, C, D) as shown below, and lift off the processor carrier assembly.




Removing the Processor from the Carrier Assembly

Unlock the lever from its locked position and push it upwards to disengage the processor from the carrier as shown below right. Carefully remove the processor from the carrier.

Processor Carrier Assembly



Note: Handle the processor with care to avoid damage.



3.4 Memory

Memory Support

The X12DPU-6 motherboard has 32 DIMM slots. It supports up to

- 8TB (DDR4 only): 3DS Load Reduced DIMM (3DS LRDIMM), 3DS Registered DIMM (3DS RDIMM), or Non-Volatile DIMMs (NV-DIMM) ECC memory with speeds of up to 3200 MHz.
- 12TB (PMem + DDR4): 8TB of Intel Optane PMem 200 series (on Platinum, Gold and selected Silver processors only) plus 4TB of DDR4.

For validated memory, use our [Product Resources page](#).

| DDR4 Memory Support for 83xx/63xx/53xx/43xx Processors | | | | | |
|--|-------------------------------|---------------------|----------------------|--------------------------|-----------------------|
| Type | Ranks Per DIMM and Data Width | DIMM Capacity (GB) | | Speed (MT/s) and Voltage | |
| | | DRAM Density | | One DIMM per Channel | Two DIMMs per Channel |
| | | 8Gb | 16Gb | | |
| RDIMM | SRx8 | 8GB | 16GB | 3200* | 3200* |
| | SRx4 | 16GB | 32GB | | |
| | DRx8 | 16GB | 32GB | | |
| | DRx4 | 32GB | 64GB | | |
| RDIMM 3Ds | (4R/8R) x4 | 2H-64GB 4H-128GB | 2H-128GB 4H-256GB | 3200* | 3200* |
| LRDIMM | QRx4 | 64GB | 128GB | | |
| LRDIMM 3Ds | (4R/8R) x4 | 4H-128GB | 2H-128GB 4H-256GB | | |

*Only the 83xx and 63xx series support 3200MT/s; for other processors, memory speed as supported by the CPU.




Figure 3-3. Memory Slots

Guidelines Regarding Mixing DIMMs

- All DIMMs must be DDR4 or a mixture of PMem and DDR4.
- x4 and x8 DIMMs can be mixed in the same channel.
- Mixing of LRDIMMs and RDIMMs is not allowed in the same channel, across different channels, and across different sockets.
- Mixing of non-3DS and 3DS LRDIMM is not allowed in the same channel, across different channels, and across different sockets.
- Mixing of PMem modules and RDIMMs is supported
- Mixing DDR4 and PMem memory operating frequencies is not validated within a socket or across sockets. If DIMMs of different frequencies are mixed in the same channel, all DIMs will run at the highest common frequency.
- Always populate the DIMM with the higher electrical loading on a channel in DIMMx1 (farther from CPU) followed by DIMMx2.

DDR4 Memory Population Guidelines

The following memory population table was created based on guidelines provided by Intel to support ALtos motherboards.

| Memory Population for DDR4-only Configurations, 32 DIMM Slots | |
|---|--|
| CPU/DIMMs | DIMM Slots |
| 2 CPUs & 2 DIMMs* | CPU1: A1 CPU2: A1 |
| 2 CPUs & 4 DIMMs* | CPU1: A1, E1 CPU2: A1, E1 |
| 2 CPUs & 6 DIMMs | CPU1: A1, C1, E1, G1 CPU2: A1, E1 |
| 2 CPUs & 8 DIMMs* | CPU1: A1, C1, E1, G1 CPU2: A1, C1, E1, G1 |
| 2 CPUs & 10 DIMMs | CPU1: A1, B1, C1, E1, F1, G1 CPU2: A1, C1, E1, G1 |
| 2 CPUs & 12 DIMMs* | CPU1: A1, B1, C1, E1, F1, G1 CPU2: A1, B1, C1, E1, F1, G1 |
| 2 CPUs & 14 DIMMs | CPU1: A1, B1, C1, D1, E1, F1, G1, H1 CPU2: A1, B1, C1, E1, F1, G1 |
| 2 CPUs & 16 DIMMs* | CPU1: A1, B1, C1, D1, E1, F1, G1, H1 CPU2: A1, B1, C1, D1, E1, F1, G1, H1 |
| 2 CPUs & 18 DIMMs | CPU1: A1, A2, B1, C1, C2, D1, E1, E2, F1, G1, G2, H1 CPU2: A1, B1, C1, E1, F1, G1 |
| 2 CPUs & 20 DIMMs | CPU1: A1, A2, B1, C1, C2, D1, E1, E2, F1, G1, G2, H1 CPU2: A1, B1, C1, D1, E1, F1, G1, H1 |
| 2 CPUs & 22 DIMMs | CPU1: A1, A2, B1, B2, C1, C2, D1, D2, E1, E2, F1, F2, G1, G2, H1, H2 CPU2: A1, B1, C1, E1, F1, G1 |
| 2 CPUs & 24 DIMMs* | CPU1: A1, A2, B1, B2, C1, C2, D1, D2, E1, E2, F1, F2, G1, G2, H1, H2 CPU2: A1, B1, C1, D1, E1, F1, G1, H1 |
| 2 CPUs & 28 DIMMs | CPU1: A1, A2, B1, B2, C1, C2, D1, D2, E1, E2, F1, F2, G1, G2, H1, H2 CPU2: A1, A2, B1, C1, C2, D1, E1, E2, F1, G1, G2, H1 |
| 2 CPUs & 32 DIMMs* | CPU1: A1, A2, B1, B2, C1, C2, D1, D2, E1, E2, F1, F2, G1, G2, H1, H2 CPU2: A1, A2, B1, B2, C1, C2, D1, D2, E1, E2, F1, F2, G1, G2, H1, H2 |

* recommended for optimal performance

- Other Intel validated memory configurations are supported, although they may not provide optimal performance. See Intel documentation for more information.
- Must have at least one DIMM per CPU.

Optane PMem 200 Series

For 3rd Gen Intel Xeon Scalable Platinum, Gold and selected Silver processors

| Symmetric Population for Each CPU with PMem + DDR4 | | | | | | | | | | | | | | | | | | | | | |
|--|----------|----------------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|
| DDR4 & PMem | Modes | AD Inter-level | DIMM | | | | | | | | | | | | | | | | | | |
| | | | F1 | F2 | E1 | E2 | H1 | H2 | G1 | G2 | C2 | C1 | D2 | D1 | A2 | A1 | B2 | B1 | | | |
| 4 DDR4 | AD | 1 - x4 | PM | - | DDR4 | - | PM | - | DDR4 | - | - | DDR4 | - | PM | - | DDR4 | - | PM | | | |
| 4 PMem | MM | 1 - x4 | DDR4 | - | PM | - | DDR4 | - | PM | - | - | PM | - | DDR4 | - | PM | - | DDR4 | | | |
| 6 DDR4 1 PMem | AD | One - x1 | DDR4 | - | DDR4 | - | - | - | DDR4 | - | - | DDR4 | - | PM | - | DDR4 | - | DDR4 | | | |
| | | | - | - | DDR4 | - | DDR4 | - | DDR4 | - | - | DDR4 | - | DDR4 | - | DDR4 | - | PM | | | |
| | | | DDR4 | - | DDR4 | - | PM | - | DDR4 | - | - | DDR4 | - | - | - | - | DDR4 | - | DDR4 | | |
| | | | PM | - | DDR4 | - | DDR4 | - | DDR4 | - | - | DDR4 | - | - | DDR4 | - | DDR4 | - | - | | |
| | | | DDR4 | - | DDR4 | - | DDR4 | - | - | - | - | PM | - | DDR4 | - | DDR4 | - | DDR4 | - | DDR4 | |
| | | | DDR4 | - | - | - | DDR4 | - | DDR4 | - | DDR4 | - | DDR4 | - | DDR4 | - | PM | - | DDR4 | - | DDR4 |
| | | | DDR4 | - | DDR4 | - | DDR4 | - | PM | - | - | - | - | DDR4 | - | DDR4 | - | DDR4 | - | DDR4 | |
| | | | DDR4 | - | PM | - | DDR4 | - | DDR4 | - | DDR4 | - | - | DDR4 | - | DDR4 | - | - | - | DDR4 | |
| 8 DDR4 1 PMem | AD | One - x1 | DDR4 | - | DDR4 | - | DDR4 | - | DDR4 | - | - | DDR4 | - | DDR4 | PM | DDR4 | - | DDR4 | | | |
| | | | DDR4 | - | DDR4 | - | DDR4 | - | DDR4 | - | PM | DDR4 | - | DDR4 | - | DDR4 | - | DDR4 | | | |
| | | | DDR4 | - | DDR4 | PM | DDR4 | - | DDR4 | - | - | DDR4 | - | DDR4 | - | DDR4 | - | DDR4 | | | |
| | | | DDR4 | - | DDR4 | - | DDR4 | - | DDR4 | PM | - | DDR4 | - | DDR4 | - | DDR4 | - | DDR4 | | | |
| | | | DDR4 | - | DDR4 | - | DDR4 | - | DDR4 | - | - | DDR4 | PM | DDR4 | - | DDR4 | - | DDR4 | | | |
| | | | DDR4 | - | DDR4 | - | DDR4 | - | DDR4 | - | - | DDR4 | - | DDR4 | PM | DDR4 | - | DDR4 | | | |
| | | | DDR4 | PM | DDR4 | - | DDR4 | - | DDR4 | - | - | DDR4 | - | DDR4 | - | DDR4 | - | DDR4 | | | |
| | | | DDR4 | - | DDR4 | - | DDR4 | PM | DDR4 | - | - | DDR4 | - | DDR4 | - | DDR4 | - | DDR4 | | | |
| 8 DDR4 4 PMem | AD | 1 - x4 | DDR4 | - | DDR4 | PM | DDR4 | - | DDR4 | PM | PM | DDR4 | - | DDR4 | PM | DDR4 | - | DDR4 | | | |
| | MM | 2 - x2 | DDR4 | - | DDR4 | PM | DDR4 | PM | DDR4 | - | - | DDR4 | PM | DDR4 | PM | DDR4 | - | DDR4 | | | |
| | | 1 - x4 | DDR4 | PM | DDR4 | - | DDR4 | - | DDR4 | PM | PM | DDR4 | - | DDR4 | - | DDR4 | PM | DDR4 | | | |
| | | 2 - x2 | DDR4 | PM | DDR4 | - | DDR4 | PM | DDR4 | - | - | DDR4 | PM | DDR4 | - | DDR4 | PM | DDR4 | | | |
| 8 DDR4 8 PMem | AD MM | One - x8 | DDR4 | PM | DDR4 | PM | DDR4 | PM | DDR4 | PM | PM | DDR4 | PM | DDR4 | PM | DDR4 | PM | DDR4 | | | |
| 12 DDR4 2 PMem | AD | One - x2 | PM | - | DDR4 | DDR4 | DDR4 | DDR4 | DDR4 | DDR4 | DDR4 | DDR4 | DDR4 | DDR4 | DDR4 | DDR4 | - | PM | | | |
| | | | DDR4 | DDR4 | DDR4 | DDR4 | PM | - | DDR4 | DDR4 | DDR4 | DDR4 | DDR4 | DDR4 | - | PM | DDR4 | DDR4 | DDR4 | | |
| | | | DDR4 | DDR4 | PM | - | DDR4 | DDR4 | DDR4 | DDR4 | DDR4 | DDR4 | DDR4 | DDR4 | DDR4 | - | PM | DDR4 | DDR4 | | |
| | | | DDR4 | DDR4 | DDR4 | DDR4 | DDR4 | DDR4 | PM | - | - | PM | DDR4 | DDR4 | DDR4 | DDR4 | DDR4 | DDR4 | DDR4 | | |

AD: App Direct, MM: Memory Mode, PM: PMem

Validation Matrix (DDR4 DIMMs Validated with PMem 200 Series)

| DIMM Type (up to 3200) | Ranks Per DIMM & Data Width (Stack) | DIMM Capacity (GB) | |
|---------------------------|---|--------------------|-------|
| | | DRAM Density | |
| | | 8Gb | 16Gb |
| RDIMM | 1Rx8 | N/A | N/A |
| | 1Rx4 | 16GB | 32GB |
| | 2Rx8 | 16GB | 32GB |
| | 2Rx4 | 32GB | 64GB |
| RDIMM 3DS | 4Rx4 (2H) | N/A | 128GB |
| | 8Rx4 (4H) | NA | 256GB |
| LRDIMM | 4Rx4 | 64GB | 128GB |
| LRDIMM 3DS | 4Rx4 (2H) | N/A | N/A |
| | 8Rx4 (4H) | 128GB | 256GB |

PMem Notes

- PMem 200 Series are supported on 3rd gen Intel Xeon Scalable Platinum, Gold and selected Silver processors.
 - Do not mix PMem and NVDIMMs within the platform.
 - For MM, NM/FM ratio is between 1:4 and 1:16. The capacity not used for FM can be used for AD. (NM = Near Memory; FM = Far Memory).
 - Matrix targets configs for optimized PMem to DRAM cache ratio in MM and MM + AD modes.
 - For each individual population, different PMem rearrangements among channels are permitted so long as the configuration does not break X12 DP Memory population rules.
 - Ensure the same DDR4 DIMM type and capacity are used for each DDR4 + PMem population.
 - If the system detects an unvalidated config, then the system issues a BIOS warning. The CLI functionality is limited in non-POR configurations, and select commands will not be supported.
 - x4 and x8 DDR4 DIMMs cannot be mixed in the same channel in PMem configurations.
-

Installing Memory

ESD Precautions


Electrostatic Discharge (ESD) can damage electronic components including memory modules. To avoid damaging DIMM modules, it is important to handle them carefully. The following measures are generally sufficient.

- Use a grounded wrist strap designed to prevent static discharge.
- Handle the memory module by its edges only.
- Put the memory modules into the antistatic bags when not in use.


Installing Memory

Begin by removing power from the system as described in Section 3.1. Follow the memory population sequence in the table above.

1. Push the release tabs outwards on both ends of the DIMM slot to unlock it.



2. Align the key of the DIMM with the receptive point on the memory slot and with your thumbs on both ends of the module, press it straight down into the slot until the module snaps into place.



3. Press the release tabs to the locked position to secure the DIMM module into the slot.

Caution: Exercise extreme caution when installing or removing memory modules to prevent damage to the DIMMs or slots.

Removing Memory

To remove a DIMM, unlock the release tabs then pull the DIMM from the memory slot.

3.5 Motherboard Battery

The motherboard uses non-volatile memory to retain system information when system power is removed. This memory is powered by a lithium battery residing on the motherboard.

Replacing the Battery

Begin by [removing power](#) from the system.

1. Push aside the small clamp that covers the edge of the battery. When the battery is released, lift it out of the holder.
2. To insert a new battery, slide one edge under the lip of the holder with the positive (+) side facing up. Then push the other side down until the clamp snaps over it.

Note: Handle used batteries carefully. Do not damage the battery in any way; a damaged battery may release hazardous materials into the environment. Do not discard a used battery in the garbage or a public landfill. Please comply with the regulations set up by your local hazardous waste management agency to dispose of your used battery properly.




Figure 3-4. Installing the Onboard Battery

Warning: There is a danger of explosion if the onboard battery is installed upside down (which reverses its polarities). This battery must be replaced only with the same or an equivalent type recommended by the manufacturer (CR2032).

3.6 Storage Drives

The system supports twelve hot-swap 3.5" hybrid storage drive bays

The drives are mounted in tool-less drive carriers that simplify their removal from the chassis. These carriers also help promote proper airflow.

Installing Drives



Figure 3-5. Logical Drive Numbers

Removing a Hot-Swap Drive Carrier from the Chassis

1. Press the release button on the drive carrier, which will extend the drive carrier handle.
2. Use the drive carrier handle to pull the drive out of the chassis.




Figure 3-6. Removing a Drive Carrier

Installing a 3.5" Drive

1. Remove the dummy drive, which comes pre-installed in the drive carrier. Pull out the two locking clasps on the right outside of the carrier and lift out the dummy drive.
2. Position the drive above the carrier with the PCB side facing down and the connector end toward the rear of the carrier.




Figure 3-7. Installing a 3.5" Drive into a Carrier

3. Tilt the drive to insert it onto the two posts on the left inside of the carrier.
4. Push the right side of the drive fully into the carrier and allow the two spring locking clasps to secure the drive.
5. Insert the drive carrier into its bay, keeping the release button on the right. When the carrier reaches the rear of the bay, the release handle will retract.
6. Push the handle in until it clicks into its locked position




Figure 3-8. Installing a 3.5" Drive into a Carrier

Checking the Temperature of an NVMe Drive

There are two ways to check using the BMC Dashboard.

Checking a Drive

- **BMC Dashboard > Server Health > NVMe SSD** – Shows the temperatures of all NVMe drives.
- **BMC Dashboard > Server Health > Sensor Reading > NVME_SSD** – Shows the single highest temperature among all the NVMe drives.

Hot-Swap for NVMe Drives

ALtos Ultra servers support NVMe surprise hot-swap. For even better data security, NVMe orderly hot-swap is recommended. NVMe drives can be ejected and replaced remotely using the BMC Dashboard.

Note: If you are using VROC, see the [VROC section](#) in this manual instead.

Ejecting a Drive

1. **BMC Dashboard > Server Health > NVMe SSD**
2. Select Device, Group and Slot, and click **Eject**. After ejecting, the drive Status LED indicator turns green.
3. Remove the drive.

Note that *Device* and *Group* are categorized by the CPLD design architecture.

Slot is the slot number on which the NVMe drives are mounted.

Replacing the Drive

1. Insert the replacement drive.
2. **BMC Dashboard > Server Health > NVMe SSD**
3. Select Device, Group and slot and click **Insert**. The drive Status LED indicator flashes red, then turns off. The Activity LED turns blue.

3.7 System Cooling

Fans

The chassis contains four 8-cm high-performance fans. Fan speed is controlled by the BMC depending on the system temperature. If a fan fails, the remaining fans will ramp up to full speed. The system will continue to run with a failed fan, although it may shut down if the heat gets too great. Replace any failed fan at your earliest convenience with the same model. Failed fans can be identified through the BMC.

Changing a System Fan

1. Determine which fan has failed using the BMC, or if necessary, open the chassis while the system is running. Never run the server for long without the chassis cover.
2. Push the release tab and pull the failed fan from the chassis. Fans can be replaced while the system is running.
3. Replace the failed fan with an identical fan, available from ALtos. Push the new fan into the housing, making sure the air flow direction is the same.
4. Power up the system and check that the fan is working properly and that the LED on the control panel has turned off. Finish by replacing the chassis cover.




Figure 3-10. Fan Positions and Numbering

Air Shrouds

Air shrouds concentrate airflow to maximize fan efficiency. They do not require screws to install.

Installing the Standard Air Shrouds

- Position the air shrouds as illustrated in the figure below.




Figure 3-11. Installing the Standard Air Shrouds

3.8 Power Supply

The chassis features redundant power supplies. The system will continue to operate if one module fails. It should be replaced as soon as convenient. The power supply modules are hot-swappable, meaning they can be changed without powering down the system. New units can be ordered directly from ALtos or authorized distributors.

These power supplies are auto-switching capable. This feature enables them to automatically sense the input voltage and operate at a 100-120v or 180-240v.

Power Supply LEDs

On the rear of the power supply module, an LED displays the status.

- **Solid Green:** When illuminated, indicates that the power supply is on.
- **Blinking Green:** When blinking, indicates that the power supply is plugged in and turned off by the system.
- **Blinking Amber:** When blinking, indicates that the power supply has a warning condition and continues to operate.
- **Solid Amber:** When illuminated, indicates that the power supply is plugged in, and is in an abnormal state. The system might need service. Please contact ALtos technical support.

Changing the Power Supply Module:

1. Unplug the AC cord from the module to be replaced.
2. On the back of the module, push the release tab sideways, as illustrated.
3. Pull the module out using the handle.
4. Push the new power supply module into the power bay until it clicks. Replace with the same model.
5. Plug the AC power cord back into the module.




Figure 3-12. Replacing the Power Supply

3.9. PCI Expansion Slots

This system offers options for riser cards that provide custom PCIe capabilities—one Ultra Riser card, one right-facing WIO riser card, and one left-facing WIO card.




Figure 3-13. Expansion Card Chassis Slots

| PCIe Slots per Riser Card | | | |
|---------------------------|------------------|--------------------------------|---------------------------------|
| Riser Card | Part Number | Slot | Description (all PCIe 4.0) |
| Ultra Riser card | AOC-2UR668G4 | 1 | x16 FH, 10.5"L (CPU2) |
| | | 2 | x16 FH, 10.5"L (CPU2) |
| | | 3 | x8 (in x16), Internal LP (CPU1) |
| | AOC-2UR68G4-i2XT | 1 | x16 FH, 10.5"L (CPU2) |
| AOC-2UR68G4-i4XTS | 2 | x8 (in x16) FH, 10.5"L (CPU2) | |
| AOC-2UR68G4-m2TS | 3 | x8 (in x16) Internal LP (CPU2) | |
| Right-facing | RSC-WR-6 | 4 | x16 low profile (CPU1) |
| Left-facing | RSC-W2-8888G4 | 5 | x8 FH, 10.5"L (CPU2) |
| | | 6 | x8 FH, 10.5"L (CPU2) |
| | | 7 | x8 FH, 10.5"L (CPU1) |
| | | 8 | x8 FH, 10.5"L (CPU1) |
| | RSC-W2-688G4 | 5 | x16 FH, 10.5"L (CPU2) |
| | | 7 | x8 (in x16) FH, 10.5"L (CPU1) |
| RSC-W2-66G4 | 5 | x16 FH, 10.5" (CPU2) | |
| | 7 | x16 FH, 10.5" (CPU1) | |

One riser card slot may be used for a controller card that supports SAS. Up to one riser card slot may be used for a retimer card that supports NVMe.

Installing Full Height Expansion Cards




Figure 3-14. Installing Expansion Cards

Installing PCI Expansion Cards

1. Power down the system and remove the top chassis cover.
2. Remove the riser card bracket, pictured above. On the rear of the chassis, each bracket is secured by a small black plastic flip-lever with an arrow on it. Flip open the appropriate lever to release the bracket, then pull the bracket out of the chassis.
3. Insert the expansion card(s) into the riser card slot(s) while aligning the rear PCI shield.
4. Replace the riser card into the motherboard expansion slot while aligning the bracket into the chassis. Flip the black plastic lever back in place, making sure it snaps closed with a click.
5. Replace the chassis cover.

Installing the Low Profile Center Expansion Card




Figure 3-15. Installing Low Profile Expansion Card

Installing the Low Profile PCI Expansion Card ()

1. Power down the system and remove the top chassis cover.
2. If necessary, remove the full height expansion card to access the low profile riser card slot, pictured above.
3. Insert the expansion card into the riser card slot while aligning the rear PCI shield into the chassis. Add the screw to secure the PCI shield.
4. Replace the full height expansion card above the low profile card if necessary, then replace the chassis cover.

Installing the Internal Expansion Card

For most models, the Ultra riser card that holds the LAN ports also offers another internal low profile card slot (). Installation is pictured below.




Figure 3-16. Ultra Riser Bracket and Expansion Cards

See previous procedures for details to access the riser card and bracket.




Figure 3-17. Bracket for Mounting an Internal Expansion Card on the Ultra Riser Card
(four-port Ultra card shown in this example)

Ultra Riser and Expansion Cards with Optional Storage Drives

This server supports an option to add two storage drives in place of expansion cards.




Figure 3-18. Ultra Riser and Expansion Cards with Optional Storage Drives

Removing the Ultra Riser Card

To remove the Ultra riser card from the motherboard, remove one screw and lift carefully with two hands.

3.10 Cable Routing Diagram

Use this section to route or reroute cables. Proper routing is important to maintain airflow through the system. SAS cable routing depends on the model and position of the SAS controller card, so routing is not shown here.




Figure 3-19. Cable Routing Diagram



Figure 3-19. Storage Backplane BPN-SAS3-LA26A-N12 ([manual](#))

Chapter 4

Motherboard Connections

This section describes the connections on the motherboard and provides pinout definitions. Note that depending on how the system is configured, not all connections are required. The LEDs on the motherboard are also described here. A motherboard layout indicating component locations may be found in [Chapter 1](#). More detail can be found in the [Motherboard Manual](#)

Please review the Safety Precautions in [Appendix A](#) before installing or removing components.

4.1 Power Connections

Two power connections supply the motherboard and several more supply for onboard devices. **Main Power Connector**

Two proprietary main power headers are located at PSU1 and PSU2. Connect appropriate power supply units to these two headers to provide adequate power to your system.

Important: To provide adequate power to the motherboard, connect the both main power connectors and 8-pin power connectors to the power supply. Failure to do so may void the manufacturer's warranty on your power supply and motherboard.

Backplane Power Connectors & GPU Power Connectors

In addition to the main power headers, eight 8-pin power connectors are also located on the motherboard to supply power to onboard devices. GPU Power Connectors, JGPW1-4, are used for GPU devices, while JPW1-4 are used for backplane devices. Connect these connectors to your power supply to provide adequate power to your onboard devices.

| 8-pin Power Pin Definitions | |
|-----------------------------|------------|
| Pin# | Definition |
| 1 - 4 | Ground |
| 5-8 | +12V |

4.2 Headers and Connectors

Fan Headers

There are eight fan headers on the motherboard. These are 4-pin fan headers, although pins 1-3 are backward compatible with traditional 3-pin fans. Four-pin fans allow fan speeds to be controlled by Thermal Management in the BMC. When using the Thermal Management setting, use all 3-pin fans or all 4-pin fans.

| Fan Header Pin Definitions | |
|-------------------------------|----------------|
| Pin# | Definition |
| 1 | Ground (Black) |
| 2 | +12V (Red) |
| 3 | Tachometer |
| 4 | PWM Control |

SGPIO Header

A Serial General Purpose Input/Output header (T-SGPIO3) is used to communicate with the enclosure management chip on the backplane.

| SGPIO Header Pin Definitions | | | |
|---------------------------------|------------|------|------------|
| Pin# | Definition | Pin# | Definition |
| 1 | NC | 2 | NC |
| 3 | Ground | 4 | DATA Out |
| 5 | Load | 6 | Ground |
| 7 | Clock | 8 | NC |

NC = No Connection

Disk-On-Module Power Connector

Two power connectors for SATA DOM (Disk-On-Module) devices are located at JSD1 and JSD2. Connect appropriate cables here to provide power support for your Serial Link DOM devices.

| DOM Power Pin Definitions | |
|------------------------------|------------|
| Pin# | Definition |
| 1 | 5V |
| 2 | Ground |
| 3 | Ground |

TPM Header

The JTPM1 header is used to connect a Trusted Platform Module (TPM)/Port 80, which is available from ALtos. A TPM/Port 80 connector is a security device that supports encryption and authentication in hard drives. It allows the motherboard to deny access if the TPM associated with the storage drive is not installed in the system.

| Trusted Platform Module/Port 80 Header Pin Definitions | | | |
|---|----------------|------|----------------|
| Pin# | Definition | Pin# | Definition |
| 1 | P3V3 | 2 | SPI_TPM_CS_N |
| 3 | PCI-E_RESET_N# | 4 | SPI_PCH_MISO |
| 5 | SPI_PCH_CLK# | 6 | Ground |
| 7 | SPI_PCH_MOSI | 8 | N/A |
| 9 | JTPM1_P3V3A | 10 | IRQ_TPM_SPIN_N |

NVMe SMBus Headers

NVMe SMBus (I²C) headers (JNV_{I²C}3/4), used for PCI-E SMBus clock and data connections, provide hot-plug support through a dedicated SMBus interface. This feature is only available for a ALtos complete system with a proprietary NVMe add-on card and cable installed.

| NVMe SMBus Header Pin Definitions | |
|--------------------------------------|------------|
| Pin# | Definition |
| 1 | Data |
| 2 | Ground |
| 3 | Clock |
| 4 | VCCIO |

Internal Speaker/Buzzer

The Internal Speaker/Buzzer (SP1) is used to provide audible indications for various beep codes.

| Internal Buzzer Pin Definitions | | |
|------------------------------------|------------|---------------|
| Pin# | Definition | |
| 1 | Pos (+) | Beep In |
| 2 | Neg (-) | Alarm Speaker |


NCSI Connector

Use the Network Controller SideBand Interface (NCSI) connector, JNSCI, to connect a Network Interface Controller (NIC) to the motherboard.

RAID Key Header

An Intel VROC RAID Key header is located at JRK1. It supports VMD used in creating optional advanced NVMe RAID configurations.

| RAID Key Header Pin Definitions | |
|------------------------------------|--------------|
| Pin# | Definition |
| 1 | Ground |
| 2 | RAID_KEY_PU |
| 3 | Ground |
| 4 | PCH_RAID_KEY |



Note: This drawing is for illustration only. Your motherboard may look different.

Chassis Intrusion

A Chassis Intrusion header is located at JL1 on the motherboard. Attach the appropriate cable from the chassis to the header to inform you when the chassis is opened.

| Chassis Intrusion Pin Definitions | |
|--------------------------------------|-----------------|
| Pins | Definition |
| 1 | Intrusion Input |
| 2 | Ground |

4-pin BMC External I₂C Header

A System Management Bus header for the BMC is located at JIPMB1. Connect a cable to this header to use the IPMB I₂C connection on your system.

| External I ₂ C Header Pin Definitions | |
|---|---------------|
| Pin# | Definition |
| 1 | Data |
| 2 | Ground |
| 3 | Clock |
| 4 | No Connection |

Control Panel

JF1 contains header pins for various control panel connections. See the figure below for the pin locations and definitions of the control panel buttons and LED indicators.

All JF1 wires have been bundled into a single cable to simplify this connection. Make sure the red wire plugs into pin 1 as marked on the motherboard. The other end connects to the control panel PCB board.




Figure 4-1. JF1 Control Panel Pins

Power Button

The Power Button connection is located on pins 1 and 2 of JF1. Momentarily contacting both pins will power on/off the system. This button can also be configured to function as a suspend button with a setting in the BIOS. To turn off the power when the system is in suspend mode, press the button for 4 seconds or longer.

| Power Button Pin Definitions (JF1) | |
|---------------------------------------|------------|
| Pin# | Definition |
| 1 | Signal |
| 2 | Ground |

Reset Button

The Reset Button connection is located on pins 3 and 4 of JF1. Attach it to a hardware reset switch on the computer case.

| Reset Button Pin Definitions (JF1) | |
|---------------------------------------|------------|
| Pin# | Definition |
| 3 | Reset |
| 4 | Ground |

Power Fail LED

The Power Fail LED connection is located on pins 5 and 6 of JF1.

| Power Fail LED Pin Definitions (JF1) | |
|---|-----------------|
| Pin# | Definition |
| 5 | 3.3V |
| 6 | PWR Supply Fail |

Overheat (OH)/Fan Fail

Connect an LED cable to pins 7 and 8 of JF1 to use the Overheat/Fan Fail LED connections. The LED on pin 8 provides warnings of overheat or fan failure.

| OH/Fan Fail Indicator Status | |
|---------------------------------|------------|
| Status | Definition |
| Off | Normal |
| On | Overheat |
| Flashing | Fan Fail |

| OH/Fan Fail LED Pin Definitions (JF1) | |
|--|-----------------|
| Pin# | Definition |
| 7 | Blue LED |
| 8 | OH/Fan Fail LED |

NIC1/NIC2 (LAN1/LAN2)

The NIC (Network Interface Controller) LED connection for LAN port 1 is located on pins 11 and 12 of JF1, and the LED connection for LAN port 2 is on pins 9 and 10. Attach the NIC LED cables here to display network activity.

| LAN1/LAN2 LED Pin Definitions (JF1) | |
|--|-------------------|
| Pin# | Definition |
| 9 | NIC2 Activity LED |
| 10 | NIC2 Link LED |
| 11 | NIC1 Activity LED |
| 12 | NIC1 Link LED |

HDD LED/UID Switch

The HDD LED/UID Switch connection is located on pins 13 and 14 of JF1. Attach a cable to Pin 14 to show hard drive activity status. Attach a cable to pin 13 to use UID switch. Refer to the table below for pin definitions.

| HDD LED Pin Definitions (JF1) | |
|----------------------------------|-------------------------|
| Pin# | Definition |
| 13 | 3.3V Standby/UID Switch |
| 14 | HDD Active |

Power LED

The Power LED connection is located on pins 15 and 16 of JF1.

| Power LED Pin Definitions (JF1) | |
|------------------------------------|------------|
| Pin# | Definition |
| 15 | 3.3V |
| 16 | Power LED |

NMI Button

The non-maskable interrupt button header is located on pins 19 and 20 of JF1.

| NMI Button Pin Definitions (JF1) | |
|-------------------------------------|------------|
| Pin# | Definition |
| 19 | Control |
| 20 | Ground |

4.3 Input/Output Ports

See the figure below for the locations and descriptions of the I/O ports on the rear of the motherboard.




Figure 4-2. Rear I/O Ports

| Rear I/O Ports | | | |
|----------------|-------------------|---|-------------|
| # | Description | # | Description |
| 1 | USB0 (3.0) | 4 | COM1 |
| 2 | USB1 (3.0) | 5 | UID Switch |
| 3 | Dedicated BMC LAN | 6 | VGA |

LAN Ports

There is a dedicated BMC LAN port on the I/O back panel.

There can also be, two, four, or zero network LAN ports on the chassis rear provided by the Ultra riser card, depending on the [option](#) you purchased.

Unit Identifier Switch/UID LED Indicator

A Unit Identifier (UID) switch and a UID LED indicator are located on the rear of the system. When you press the UID switch, both front and rear UID LED indicators are toggled on or off. The UID indicators provide easy identification of a system in a rack.


Note: the UID can also be triggered using the BMC.

4.4 Jumpers

Explanation of Jumpers

To modify the operation of the motherboard, jumpers are used to choose between optional settings. Jumpers create shorts between two pins to change the function associated with it. Pin 1 is identified with a square solder pad on the printed circuit board. See the motherboard layout page for jumper locations.

Note: On a two-pin jumper, "Closed" means the jumper is on both pins and "Open" indicates the jumper is either on only one pin or has been completely removed.



Watchdog

JWD1 controls the Watchdog function. Watchdog is a monitor that can reboot the system when a software application hangs. Jumping pins 1-2 will cause Watch Dog to reset the system if an application hangs. Jumping pins 2-3 will generate a non-maskable interrupt signal for the application that hangs. Watchdog must also be enabled in BIOS. The default setting is Reset.

Note: When Watchdog is enabled, the user must write their own application software to disable it.

| Watchdog Jumper Settings | |
|--------------------------|------------|
| Jumper Setting | Definition |
| Pins 1-2 | Reset |
| Pins 2-3 | NMI |
| Open | Disabled |

BMC Enable

Use Jumper JPB1 to enable or disable the onboard Baseboard Management Controller (BMC), which provides system health management/monitoring and network interface using the BMC. The default setting is on pins 1-2 to enable the connection for BMC support.

| BMC Enable/Disable Jumper Settings | |
|------------------------------------|------------|
| Jumper Setting | Definition |
| Pins 1-2 | Enabled |
| Pins 2-3 | Disabled |

VGA/Video Display Enable

Jumper JPG1 enables or disables onboard VGA support. When this jumper is set to Disabled, both rear VGA port, located at I/O back panel, and the optional front accessible VGA header, located at JVGA2 are disabled. The default setting is on pins 1-2 to enable the connection for VGA support.

| VGA Enable/Disable Jumper Settings | |
|------------------------------------|------------|
| Jumper Setting | Definition |
| Pins 1-2 | Enabled |
| Pins 2-3 | Disabled |

4.5 LED Indicators

Network LAN LEDs

The Ethernet ports each have two LEDs. One LED indicates activity when flashing green. The other may be green, amber or off to indicate the speed of the connection. [Speeds](#) are noted in Chapter 1.

Dedicated BMC LAN LEDs

A dedicated BMC LAN port is also included on the motherboard. The amber LED on the right of the BMC LAN port indicates activity, while the LED color on the left indicates the speed of the connection.

| BMC Link LED | |
|--------------|---------------|
| Color | Definition |
| Off | No Connection |
| Green | 100 Mb/s |
| Amber | 1 Gb/s |



Unit ID LED

A rear unit identifier (UID) indicator at LED1 is located near the UID switch on the I/O back panel. It provides easy identification of a unit that may need service.

Onboard Power LED

The Onboard Power LED is LE2. When this LED is on, the system power is on.

BMC Heartbeat LED

LEDM1 is the BMC heartbeat LED. When the LED is blinking green, BMC is functioning normally.

4.6 Storage Ports

I-SATA 3.0 and S-SATA 3.0 Ports

The R380 F5 has eight I-SATA 3.0 ports (I-SATA 0-3, I-SATA 4-7) and six S-SATA (S-SATA 0-3, S-SATA 4, S-SATA 5) on the motherboard. These SATA ports are supported by the Intel PCH C621 chipset. S-SATA 4/S-SATA 5 can be used with ALtos SuperDOMs which are orange SATA DOM connectors with power pins built in, and do not require external power cables. ALtos SuperDOMs are compatible with regular SATA HDDs or SATA DOMs that need external power cables.

NVMe Connectors

Five NVMe connectors (P1_NVMe1/3/4/5/6), supported by Processor #1, provide five NVMe connections. In addition, four NVMe connectors (P2_NVMe7/8/9/10), supported by Processor #2, also provide four NVMe connections on the motherboard. Use these NVMe connections to support high-speed PCI-E storage devices.

Note: When installing an NVMe device on a motherboard, please be sure to connect the first NVMe port (P1_NVMe1) first for your system to work properly.

Appendix A

Standardized Warning Statements for AC Systems

About Standardized Warning Statements

The following statements are industry standard warnings, provided to warn the user of situations which have the potential for bodily injury. Should you have questions or experience difficulty, contact ALtos's Technical Support department for assistance. Only certified technicians should attempt to install or configure components.

Read this appendix in its entirety before installing or configuring components in the ALtos chassis.

Warning Definition



Warning! This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents.

警告の定義

この警告サインは危険を意味します。

人身事故につながる可能性がありますので、いずれの機器でも動作させる前に、電気回路に含まれる危険性に注意して、標準的な事故防止策に精通して下さい。

此警告符号代表危險。

您正处于可能受到严重伤害的工作环境中。在您使用设备开始工作之前，必须充分意识到触电的危险，并熟练掌握防止事故发生的标准工作程序。请根据每项警告结尾的声明号码找到此设备的安全性警告说明的翻译文本。

此警告符號代表危險。

您正處於可能身體可能會受損傷的工作環境中。在您使用任何設備之前，請注意觸電的危險，並且要熟悉預防事故發生的標準工作程序。請依照每一注意事項後的號碼找到相關的翻譯說明內容。

Warnung

WICHTIGE SICHERHEITSHINWEISE

Dieses Warnsymbol bedeutet Gefahr. Sie befinden sich in einer Situation, die zu Verletzungen führen kann. Machen Sie sich vor der Arbeit mit Geräten mit den Gefahren elektrischer Schaltungen und den üblichen Verfahren zur Vorbeugung vor Unfällen vertraut. Suchen Sie mit der am Ende jeder Warnung angegebenen Anweisungsnummer nach der jeweiligen Übersetzung in den übersetzten Sicherheitshinweisen, die zusammen mit diesem Gerät ausgeliefert wurden.

BEWAHREN SIE DIESE HINWEISE GUT AUF.

INSTRUCCIONES IMPORTANTES DE SEGURIDAD

Este símbolo de aviso indica peligro. Existe riesgo para su integridad física. Antes de manipular cualquier equipo, considere los riesgos de la corriente eléctrica y familiarícese con los procedimientos estándar de prevención de accidentes. Al final de cada advertencia encontrará el número que le ayudará a encontrar el texto traducido en el apartado de traducciones que acompaña a este dispositivo.

GUARDE ESTAS INSTRUCCIONES.

IMPORTANTES INFORMATIONS DE SÉCURITÉ

Ce symbole d'avertissement indique un danger. Vous vous trouvez dans une situation pouvant entraîner des blessures ou des dommages corporels. Avant de travailler sur un équipement, soyez conscient des dangers liés aux circuits électriques et familiarisez-vous avec les procédures couramment utilisées pour éviter les accidents. Pour prendre connaissance des traductions des avertissements figurant dans les consignes de sécurité traduites qui accompagnent cet appareil, référez-vous au numéro de l'instruction situé à la fin de chaque avertissement.

CONSERVEZ CES INFORMATIONS.

הרהזא תורהצה ןונקת

הלבה ינפמ שמתשמה תא ריהזהל תנמ לע, היישעתה ינקת יפ לע תורהזא ןה תואבה תורהצה הכימת תקלחמ ׁע רשק רוציל שי, יהשלכ היעבב תולקתיה וא תולאש שיו הדימב. תירשפא תיזיפ מיביכרה תא רידגהל וא ןיקתהל מיאשר דבלב מיכמסומ מיאנכט. ורקמרפוס לש .

תינכט. ורקמרפוס יזראמב מיביכרה תרדגה וא תנקתה ינפל ואולמב חפסנה תא אורקל שי

ا َك ف حالةٌ يكو اى تتسبب ف اصابة جسدة هذا الزهزُح خطرٌ اِتحدُز . قبل اى تعول عدل
اى هعدات،يك عدل علن بالوخاطر الاجوة عي الذوائز الكهزبائىة وبك عدل دراة بالووارسات
النقائىة لوع وقع اى حداثث
استخدم رفن الب اى الوصص ف هاة كل تحدُز للعثر تزجوتها

안전을 위한 주의사항

경고!

이 경고 기호는 위험이 있음을 알려 줍니다. 작업자의 신체에 부상을 야기 할 수 있는 상태에 있게 됩니다. 모든 장비에 대한 작업을 수행하기 전에 전기회로와 관련된 위험요소들을 확인하시고 사전에 사고를 방지할 수 있도록 표준 작업절차를 준수해 주시기 바랍니다.

해당 번역문을 찾기 위해 각 경고의 마지막 부분에 제공된 경고문 번호를 참조하십시오

BELANGRIJKE VEILIGHEIDSINSTRUCTIES

Dit waarschuwings symbool betekent gevaar. U verkeert in een situatie die lichamelijk letsel kan veroorzaken. Voordat u aan enige apparatuur gaat werken , dient u zich bewust te zijn van de bij een elektrische installatie betrokken risico's en dient u op de hoogte te zijn van de standaard procedures om ongelukken te voorkomen. Gebruik de nummers aan het eind van elke waarschuwing om deze te herleiden naar de desbetreffende locatie.

BEWAAR DEZE INSTRUCTIES

Installation Instructions



Warning! Read the installation instructions before connecting the system to the power source.

設置手順書

システムを電源に接続する前に、設置手順書をお読み下さい。

警告

将此系统连接电源前,请先阅读安装说明。

警告

將系統與電源連接前，請先閱讀安裝說明。

Warnung

Vor dem Anschließen des Systems an die Stromquelle die Installationsanweisungen lesen.

¡Advertencia!

Lea las instrucciones de instalación antes de conectar el sistema a la red de alimentación.

Attention

Avant de brancher le système sur la source d'alimentation, consulter les directives d'installation.

חתם רוקמל תכרעמה רוביח ינפל הנקתה תוארוה תא אורקל שי.

نقاطل ردصم لبأ ماظنلا ليصوت لبق بيكترلا تاداشر! رقا

시스템을 전원에 연결하기 전에 설치 안내를 읽어주십시오.

Waarschuwing

Raadpleeg de installatie-instructies voordat u het systeem op de voedingsbron aansluit.

Circuit Breaker



Warning! This product relies on the building's installation for short-circuit (overcurrent) protection. Ensure that the protective device is rated not greater than: 250 V, 20 A.

サーキット・ブレーカー

この製品は、短絡(過電流)保護装置がある建物での設置を前提としています。

保護装置の定格が **250 V**、**20 A** を超えないことを確認下さい。

警告

此产品的短路(过载电流)保护由建筑物的供电系统提供,确保短路保护设备的额定电流不大于 250V,20A。

警告

此產品的短路(過載電流)保護由建築物的供電系統提供,確保短路保護設備的額定電流不大於 250V,20A。

Warnung

Dieses Produkt ist darauf angewiesen, dass im Gebäude ein Kurzschluss- bzw. Überstromschutz installiert ist. Stellen Sie sicher, dass der Nennwert der Schutzvorrichtung nicht mehr als: 250 V, 20 A beträgt.

¡Advertencia!

Este equipo utiliza el sistema de protección contra cortocircuitos (o sobrecorrientes) del edificio. Asegúrese de que el dispositivo de protección no sea superior a: 250 V, 20 A.

Attention

Pour ce qui est de la protection contre les courts-circuits (surtension), ce produit dépend de l'installation électrique du local. Vérifiez que le courant nominal du dispositif de protection n'est pas supérieur à :250 V, 20 A.

יכ אדווול שי ילמשח רצק תעינמל סינבמב תנקתומה הנגה לע דמתסמ הז
מ רתוי אל אוה ילמשחה רצקה ינפמ וגמה רישכמה-20A, 250V רצומ

في اهتبيثت مت يتلا قيرصقلار ئاودلا هم تيماحلا ئادعم لع دمتعي جتنلما اذه
بنبلما

نم ثركأ سيل ئياقولا زاهجلا مبيقت نا نم دكات : 20A, 250V

경고!

이 제품은 전원의 단락(과전류)방지에 대해서 전적으로 건물의 관련 설비에 의존합니다.
보호장치의 정격이 반드시 250V(볼트), 20A(암페어)를 초과하지 않도록 해야 합니다.


Waarschuwing

Dit product is afhankelijk van de kortsluitbeveiliging (overspanning) van uw elektrische installatie.
Controleer of het beveiligde apparaat niet groter gedimensioneerd is dan 250V, 20A.

Power Disconnection Warning



Warning! The system must be disconnected from all sources of power and the power cord removed from the power supply module(s) before accessing the chassis interior to install or remove system components.



電源切断の警告

システムコンポーネントの取り付けまたは取り外しのために、シャーシ内部にアクセスするには、

システムの電源はすべてのソースから切断され、電源コードは電源モジュールから取り外す必要があります。

警告

在你打开机箱并安装或移除内部器件前,必须将系统完全断电,并移除电源线。

警告

在您打開機殼安裝或移除內部元件前，必須將系統完全斷電，並移除電源線。

Warnung

Das System muss von allen Quellen der Energie und vom Netzanschlusskabel getrennt sein, das von den Spg.Versorgungsteilmodulen entfernt wird, bevor es auf den Chassisinnenraum zurückgreift, um Systemsbestandteile anzubringen oder zu entfernen.

¡Advertencia!

El sistema debe ser disconnected de todas las fuentes de energía y del cable eléctrico quitado de los módulos de fuente de alimentación antes de tener acceso el interior del chasis para instalar o para quitar componentes de sistema.

Attention

Le système doit être débranché de toutes les sources de puissance ainsi que de son cordon d'alimentation secteur avant d'accéder à l'intérieur du chassis pour installer ou enlever des composants de système.

ילמשח קותינ ינפמ הרהזא

הרהזא!

קפסהמ ילמשחה לבכ תא ריסהל שיו למשחה תורוקמ לכמ תכרעמה תא קתנל
שי מיביכר תרסה וא תנקתה ךרוצל זראמה לש ימינפה קלחל השיג ינפל

דאדמא ءدحو نم ءابر هكنا كهس تناز او تقاطنا رداصم عيمج نم واطننا مصف بجي
مبق تقاطنا

زاهجلا ثانكم تناز او جيبثتن مكيهن تيهادنا قطاننما نبا لئصنا

경고!

시스템에 부품들을 장착하거나 제거하기 위해서는 새시 내부에 접근하기 전에 반드시 전원 공급장치로부터 연결되어있는 모든 전원과 전기코드를 분리해주어야 합니다.

Waarschuwing

Voordat u toegang neemt tot het binnenwerk van de behuizing voor het installeren of verwijderen van systeem onderdelen, dient u alle spanningsbronnen en alle stroomkabels aangesloten op de voeding(en) van de behuizing te verwijderen

Equipment Installation



Warning! Only trained and qualified personnel should be allowed to install, replace, or service this equipment.

機器の設置

トレーニングを受け認定された人だけがこの装置の設置、交換、またはサービスを許可されています。

警告

只有经过培训且具有资格的人员才能进行此设备的安装、更换和维修。

警告

只有經過受訓且具資格人員才可安裝、更換與維修此設備。

Warnung

Das Installieren, Ersetzen oder Bedienen dieser Ausrüstung sollte nur geschultem, qualifiziertem Personal gestattet werden.

¡Advertencia!

Solamente el personal calificado debe instalar, reemplazar o utilizar este equipo.

Attention

Il est vivement recommandé de confier l'installation, le remplacement et la maintenance de ces équipements à des personnels qualifiés et expérimentés.

הרהזא!

דויצה רובע תוריש תתל וא דויצה תא פילחהל, ויקתהל יאשר דבלב דמסומ תווצ.

هيهولما هيفظملل طقف حمسي نأ بجي ساهجلا اذه تمدخ وأ لادبتساو بيكرتل هيبيردلماو

경고!

훈련을 받고 공인된 기술자만이 이 장비의 설치, 교체 또는 서비스를 수행할 수 있습니다.

Waarschuwing

Deze apparatuur mag alleen worden geïnstalleerd, vervangen of hersteld door geschoold en gekwalificeerd personeel.

Restricted Area



Warning! This unit is intended for installation in restricted access areas. A restricted access area can be accessed only through the use of a special tool, lock and key, or other means of security. (This warning does not apply to workstations).

アクセス制限区域

このユニットは、アクセス制限区域に設置されることを想定しています。

アクセス制限区域は、特別なツール、鍵と錠前、その他のセキュリティの手段を用いてのみ出入りが可能です。

警告

此部件应安装在限制进出的场所，限制进出的场所指只能通过使用特殊工具、锁和钥匙或其它安全手段进出的场所。

警告

此装置仅限安装於進出管制區域，進出管制區域係指僅能以特殊工具、鎖頭及鑰匙或其他安全方式才能進入的區域。

Warnung

Diese Einheit ist zur Installation in Bereichen mit beschränktem Zutritt vorgesehen. Der Zutritt zu derartigen Bereichen ist nur mit einem Spezialwerkzeug, Schloss und Schlüssel oder einer sonstigen Sicherheitsvorkehrung möglich.

¡Advertencia!

Esta unidad ha sido diseñada para instalación en áreas de acceso restringido. Sólo puede obtenerse acceso a una de estas áreas mediante la utilización de una herramienta especial, cerradura con llave u otro medio de seguridad.

Attention

Cet appareil doit être installée dans des zones d'accès réservés. L'accès à une zone d'accès réservé n'est possible qu'en utilisant un outil spécial, un mécanisme de verrouillage et une clé, ou tout autre moyen de sécurité.

תלבגומ השיג מע רוזא

הרהזא!

תרזעב תנתני השיגה. השיג תלבגה מהב שיש מירוזאב הדיחיה תא ויקתהל שי
(דכו לוענמ, חתפמ) דבלב החטבא ילכ

مت ةروظحم قطانم ف اهب كرتن ةذحننا هذه صيصخت تصاخ ةادأ .
وانختسا للاخ نم طقف ةروظحم تقطنم نا لصدنا نكم، حاتفمو مفق
امملا لان یرخأ ته سو أ وأ

경고!

이 장치는 접근이 제한된 구역에 설치하도록 되어있습니다. 특수도구, 잠금 장치 및 키, 또는 기타 보안 수단을 통해서만 접근 제한 구역에 들어갈 수 있습니다.

Waarschuwing

Dit apparaat is bedoeld voor installatie in gebieden met een beperkte toegang. Toegang tot dergelijke gebieden kunnen alleen verkregen worden door gebruik te maken van speciaal gereedschap, slot en sleutel of andere veiligheidsmaatregelen.

Battery Handling



Warning! There is the danger of explosion if the battery is replaced incorrectly. Replace the battery only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions

電池の取り扱い

電池交換が正しく行われなかった場合、破裂の危険性があります。交換する電池はメーカーが推奨する型、または同等のものを使用下さい。使用済電池は製造元の指示に従って処分して下さい。

警告

電池更換不當會有爆炸危險。請只使用同類電池或製造商推薦的功能相當的電池更換原有電池。請按製造商的說明處理廢舊電池。

警告

電池更換不當會有爆炸危險。請使用製造商建議之相同或功能相當的電池更換原有電池。請按照製造商的說明指示處理廢棄舊電池。

Warnung

Bei Einsetzen einer falschen Batterie besteht Explosionsgefahr. Ersetzen Sie die Batterie nur durch den gleichen oder vom Hersteller empfohlenen Batterietyp. Entsorgen Sie die benutzten Batterien nach den Anweisungen des Herstellers.

Attention

Danger d'explosion si la pile n'est pas remplacée correctement. Ne la remplacer que par une pile de type semblable ou équivalent, recommandée par le fabricant. Jeter les piles usagées conformément aux instructions du fabricant.

¡Advertencia!

Existe peligro de explosión si la batería se reemplaza de manera incorrecta. Reemplazar la batería exclusivamente con el mismo tipo o el equivalente recomendado por el fabricante. Desechar las baterías gastadas según las instrucciones del fabricante.

הרהזא!

פילחהל שי. הניקת אל ךרדב הפלחוהו הדימב הללוסה לש ןוציפ תנכס תמייק תצלמומ ןרצי תרבחמ סאותה גוסב הללוסה תא.
ןרציה תוארוה יפל עצבל שי תושמושמה תוללוסה קוליס.

هناك خطر من انفجار يف حالة اسحبذال البطارية بطريقة غري صحيحة فعليل
اسحبذال البطارية
فقط بنفس النوع أو ما يعادلها مام أو صت به الرشمة املصنعة
جخلص من البطاريات املسعملة وفقا لعلليامت الرشمة الصانعة

경고!

배터리가 올바르게 교체되지 않으면 폭발의 위험이 있습니다. 기존 배터리와 동일하거나 제조사에서 권장하는 동등한 종류의 배터리로만 교체해야 합니다. 제조사의 안내에 따라 사용된 배터리를 처리하여 주십시오.

Waarschuwing

Er is ontploffingsgevaar indien de batterij verkeerd vervangen wordt. Vervang de batterij slechts met hetzelfde of een equivalent type die door defabrikant aanbevolen wordt. Gebruikte batterijen dienen overeenkomstig fabrieksvoorschriften afgevoerd te worden.

Redundant Power Supplies



Warning! This unit might have more than one power supply connection. All connections must be removed to de-energize the unit.

冗長電源装置

このユニットは複数の電源装置が接続されている場合があります。
ユニットの電源を切るためには、すべての接続を取り外さなければなりません。

警告

此部件连接的电源可能不止一个，必须将所有电源断开才能停止给该部件供电。

警告

此裝置連接的電源可能不只一個，必須切斷所有電源才能停止對該裝置的供電。

Warnung

Dieses Gerät kann mehr als eine Stromzufuhr haben. Um sicherzustellen, dass der Einheit kein Strom zugeführt wird, müssen alle Verbindungen entfernt werden.

¡Advertencia!

Puede que esta unidad tenga más de una conexión para fuentes de alimentación. Para cortar por completo el suministro de energía, deben desconectarse todas las conexiones.

Attention

Cette unité peut avoir plus d'une connexion d'alimentation. Pour supprimer toute tension et tout courant électrique de l'unité, toutes les connexions d'alimentation doivent être débranchées.

דחא קפסמ רתוי מייק מא

הרהזא!

נקורל תנמ לע מירוביחה לכ תא ריסהל שי. קפס לש דחא רוביחמ רתוי שי הדחיל
הדיחיה תא.

عقاطلا دادما تادحوب تلاصتا عدع زاهجلا اذهل نوكي دق .
ءابر هكلا نع ءدحولا لسعل تلاصتلا ءفاك ءلازإ بجي

경고!

이 장치에는 한 개 이상의 전원 공급 단자가 연결되어 있을 수 있습니다. 이 장치에 전원을 차단하기 위해서는 모든 연결 단자를 제거해야만 합니다.

Waarschuwing

Deze eenheid kan meer dan één stroomtoevoeraansluiting bevatten. Alle aansluitingen dienen verwijderd te worden om het apparaat stroomloos te maken.

Backplane Voltage



Warning! Hazardous voltage or energy is present on the backplane when the system is operating. Use caution when servicing.

バックプレーンの電圧

システムの稼働中は危険な電圧または電力が、バックプレーン上にかかっています。

修理する際には注意ください。

警告

当システム正在进行时，背板上有很危险的电压或能量，进行维修时务必小心。

警告

當系統正在進行時，背板上危險的電壓或能量，進行維修時務必小心。

Warnung

Wenn das System in Betrieb ist, treten auf der Rückwandplatine gefährliche Spannungen oder Energien auf. Vorsicht bei der Wartung.

¡Advertencia!

Cuando el sistema está en funcionamiento, el voltaje del plano trasero es peligroso. Tenga cuidado cuando lo revise.

Attention

Lorsque le système est en fonctionnement, des tensions électriques circulent sur le fond de panier. Prendre des précautions lors de la maintenance.

ירוחאה לנפב חתמ

הרהזא!

ךלהמב רהזיהל שי. תכרעמה לועפת ןמזב ירוחאה לנפב חתמ תנכס תמייק הדובעה.

تحذيراً ليع قد يجلب ما قاطلاً أو يباين هكلاً رايتلاً هم زطخ كانه سا هجلاً اذه

تمدخ دنع ارضح هك لمعي ماظنلاً ننكي امدنع

경고!

시스템이 동작 중일 때 후면판 (Backplane)에는 위험한 전압이나 에너지가 발생 합니다.
서비스 작업 시 주의하십시오.

Waarschuwing

Een gevaarlijke spanning of energie is aanwezig op de backplane wanneer het systeem in gebruik is. Voorzichtigheid is geboden tijdens het onderhoud.

Comply with Local and National Electrical Codes



Warning! Installation of the equipment must comply with local and national electrical codes.

地方および国の電気規格に準拠

機器の取り付けはその地方および国の電気規格に準拠する必要があります。

警告

设备安装必须符合本地与本国电气法规。

警告

設備安裝必須符合本地與本國電氣法規。

Warnung

Die Installation der Geräte muss den Sicherheitsstandards entsprechen.

¡Advertencia!

La instalación del equipo debe cumplir con las normas de electricidad locales y nacionales.

Attention

L'équipement doit être installé conformément aux normes électriques nationales et locales.

יצראה למשחה יקוח מואית

הרהזא!

סייצראהו סייוקמה למשחה יקוחל תמאות תויהל תבייח דויצה תנקתה.

ةقلعلما ةييطلاو ةيلحما هيوانقل لثتيم نا بجي ةينابر هكلا

تادعلما بيكرت ءابر هكلاب

경고!

현 지역 및 국가의 전기 규정에 따라 장비를 설치해야 합니다.

Waarschuwing

Bij installatie van de apparatuur moet worden voldaan aan de lokale en nationale elektriciteitsvoorschriften.

Product Disposal



Warning! Ultimate disposal of this product should be handled according to all national laws and regulations.

製品の廃棄

この製品を廃棄処分する場合、国の関係する全ての法律・条例に従い処理する必要があります。

警告

本产品的废弃处理应根据所有国家的法律和规章进行。

警告

本產品的廢棄處理應根據所有國家的法律和規章進行。

Warnung

Die Entsorgung dieses Produkts sollte gemäß allen Bestimmungen und Gesetzen des Landes erfolgen.

¡Advertencia!

Al deshacerse por completo de este producto debe seguir todas las leyes y reglamentos nacionales.

Attention

La mise au rebut ou le recyclage de ce produit sont généralement soumis à des lois et/ou directives de respect de l'environnement. Renseignez-vous auprès de l'organisme compétent.

רצומה קוליס

הרהזא!

הנידמה יקוחו תויחנהל סאתהב תויהל בייח הז רצומ לש יפוס קוליס.

دنع قينطلا حنامللاو بينانقلا عيمجل افوو هعم لمانعلا يغبني جنتلما اذه نم نياهنلا صلختلا

경고!

이 제품은 해당 국가의 관련 법규 및 규정에 따라 폐기되어야 합니다.

Waarschuwing

De uiteindelijke verwijdering van dit product dient te geschieden in overeenstemming met alle nationale wetten en reglementen.

Hot Swap Fan Warning



Warning! Hazardous moving parts. Keep away from moving fan blades. The fans might still be turning when you remove the fan assembly from the chassis. Keep fingers, screwdrivers, and other objects away from the openings in the fan assembly's housing.

ファン・ホットスワップの警告

警告！回転部品に注意。運転中は回転部(羽根)に触れないでください。シャーシから冷却ファン装置を取り外した際、ファンがまだ回転している可能性があります。ファンの開口部に、指、ドライバー、およびその他のものを近づけないで下さい。

警告!

警告！危險的可移動性零件。請務必與轉動的风扇叶片保持距離。當您從機架移除風扇裝置，風扇可能仍在轉動。小心不要將手指、螺絲起子和其他物品太靠近風扇

警告

危險的可移動性零件。請務必與轉動的风扇叶片保持距離。當您從機架移除風扇裝置，風扇可能仍在轉動。小心不要將手指、螺絲起子和其他物品太靠近風扇。

Warnung

Gefährlich Bewegende Teile. Von den bewegenden Lüfterblätter fern halten. Die Lüfter drehen sich u. U. noch, wenn die Lüfterbaugruppe aus dem Chassis genommen wird. Halten Sie Finger, Schraubendreher und andere Gegenstände von den Öffnungen des Lüftergehäuses entfernt.

¡Advertencia!

Riesgo de piezas móviles. Mantener alejado de las aspas del ventilador. Los ventiladores podran dar vuelta cuando usted quite el montaje del ventilador del chasis. Mantenga los dedos, los destornilladores y todos los objetos lejos de las aberturas del ventilador

Attention

Pieces mobiles dangereuses. Se tenir a l'ecart des lames du ventilateur Il est possible que les ventilateurs soient toujours en rotation lorsque vous retirerez le bloc ventilateur du châssis. Prenez garde à ce que doigts, tournevis et autres objets soient éloignés du logement du bloc ventilateur.

הרהזא!

יקלח תא מיריסמ רשאכהלועפב ררוואמה יבהלמ קחרתה. מינכוסמ מיענ מיקלח תא חוטב קחרמל קיחרהל שי. מידבוע ויידע מיררוואמהו נכתי, זראמהמ ררוואמה ררוואמה יותב מיחתפהמ מינוש הדובע ילכו תועבצאה

نأ نكملما نم. نكرحتلما قحورلما تارفش نع دعتبا. قرطخ نكرحتم ءازجا! رينحت عبالا ءاقبا بجى

لكيهلا نم قحورلما نللك ءلازا دنعرودت لازت لا حوارلما قحورلما نللك في تاحتقلا نع اديعب ءايشلا

نم اهرىغو يغبائر لا تاكفمو

경고!

움직이는 위험한 부품. 회전하는 송풍 날개에 접근하지 마세요. 새시로부터 팬 조립품을 제거할 때 팬은 여전히 회전하고 있을 수 있습니다. 팬 조립품 외관의 열려있는 부분들로부터 손가락 및 스크류드라이버, 다른 물체들이 가까이 하지 않도록 배치해 주십시오.

Waarschuwing

Gevaarlijk bewegende onderdelen. Houd voldoende afstand tot de bewegende ventilatorbladen. Het is mogelijk dat de ventilator nog draait tijdens het verwijderen van het ventilatorsamenstel uit het chassis. Houd uw vingers, schroevendraaiers en eventuele andere voorwerpen uit de buurt van de openingen in de ventilatorbehuizing.

Power Cable and AC Adapter



Warning! When installing the product, use the provided or designated connection cables, power cables and AC adapters. Using any other cables and adapters could cause a malfunction or a fire. Electrical Appliance and Material Safety Law prohibits the use of UL or CSA -certified cables (that have UL/CSA shown on the cord) for any other electrical devices than products designated by ALtos only.

電源コードと AC アダプター

製品を設置する場合、提供または指定および購入された接続ケーブル、電源コードと AC アダプターを 該当する地域の条例や安全基準に適合するコードサイズやプラグと共に使用下さい。他のケーブルやアダプタを使用すると故障や火災の原因になることがあります。

電気用品安全法は、UL または CSA 認定のケーブル(UL/CSA マークがコードに表記)を ALtos が指定する製品以外に使用することを禁止しています。

警告

安装此产品时,请使用本身提供的或指定的或采购的连接线,电源线和电源适配器。包含遵照当地法规和要求的合规的电源线尺寸和插头。使用其它线材或适配器可能会引起故障或火灾。除了 ALtos 所指定的产品,电气用品和材料安全法律规定禁止使用未经 UL 或 CSA 认证的线材。(线材上会显示 UL/CSA 符号)。

警告

安裝此產品時,請使用本身提供的或指定的或採購的連接線,電源線和電源適配器。包含遵照當地法規和安全要求的合規的電源線尺寸和插頭。使用其它線材或適配器可能會引起故障或火災。除了 ALtos 所指定的產品,電氣用品和材料安全法律規定禁止使用未經 UL 或 CSA 認證的線材。(線材上會顯示 UL/CSA 符號)。

Warnung

Nutzen Sie beim Installieren des Produkts ausschließlich die von uns zur Verfügung gestellten Verbindungskabeln, Stromkabeln und/oder Adapter, die Ihre örtlichen Sicherheitsstandards einhalten. Der Gebrauch von anderen Kabeln und Adapter können Fehlfunktionen oder Feuer verursachen. Die Richtlinien untersagen das Nutzen von UL oder CAS zertifizierten Kabeln (mit UL/CSA gekennzeichnet), an Geräten oder Produkten die nicht mit ALtos gekennzeichnet sind.

¡Advertencia!

Cuando instale el producto, utilice la conexión provista o designada o procure cables , Cables de alimentación y adaptadores de CA que cumplan con los códigos locales y los requisitos de seguridad, incluyendo el tamaño adecuado del cable y el enchufe. El uso de otros cables y adaptadores podría causar un mal funcionamiento o un incendio. La Ley de Seguridad de Aparatos Eléctricos y de Materiales prohíbe El uso de cables certificados por UL o CSA (que tienen el certificado UL / CSA en el código) para cualquier otros dispositivos eléctricos que los productos designados únicamente por ALtos.

Attention

Lors de l'installation du produit, utilisez les cables de connection fournis ou désigné ou achetez des cables, cables de puissance et adaptateurs respectant les normes locales et les conditions de securite y compris les tailles de cables et les prises electriques appropries. L'utilisation d'autres cables et adaptateurs peut provoquer un dysfonctionnement ou un incendie. Appareils électroménagers et la Loi sur la Sécurité Matériel interdit l'utilisation de câbles certifiés- UL ou CSA (qui ont UL ou CSA indiqué sur le code) pour tous les autres appareils électriques sauf les produits désignés par ALtos seulement.

AC כבלים חשמליים ומתאמי

אזהרה!

אשר נרכשו או הותאמו לצורך AC כאשר מתקינים את המוצר, יש להשתמש בכבלים, ספקים ומתאמים ההתקנה, ואשר הותאמו לדרישות הבטיחות המקומיות, כולל מידה נכונה של הכבל והתקע. שימוש בכל כבל או מתאם מסוג אחר, עלול לגרום לתקלה או קצר חשמלי. בהתאם לחוקי השימוש במכשירי החשמל וחוקי כאשר מופיע עליהם קוד של) UL או ב-UL -הבטיחות, קיים איסור להשתמש בכבלים המוסמכים בבלבד ALtos עבור כל מוצר חשמלי אחר, אלא רק במוצר אשר הותאם ע"י (UL/CSA).

תאבאקלא ארשב מץ וא דדחמלא וא ערפוטמלא תאליסוטלא מאדחטסאב מץ ,גתנתמלא בייקרט דנע
כלז יפ אמב עילחמלא עמאלסלא תאבלטמו נינאוץב מאז תלאלא עמ דדרתמלא ראיתלא תאלוחמו עינאבר הכלא
קירח וא לטע יפ בייסטי דץ ברחא תאלוחמו תאלבאק יא מאדחטסא .מילסלא סבאקלאו לסומלא מץב CSA וא UL לייק נמ דדמעתמלא תאבאקלא
מאדחטסא תאדעמלאו עינאבר הכלא עז הגאלל עמאלסלא נונאק רטחי
ALtos לייק נמ דדחמלאו עינעמלא תאגתנתמלא רייג ברחא תאדעמ יא עמ(UL/CSA) עמאלע למחט יתלאו

전원 케이블 및 AC 어댑터

경고! 제품을 설치할 때 현지 코드 및 적절한 굵기의 코드와 플러그를 포함한 안전 요구 사항을 준수하여 제공되거나 지정된 연결 혹은 구매 케이블, 전원 케이블 및 AC 어댑터를 사용하십시오.

다른 케이블이나 어댑터를 사용하면 오작동이나 화재가 발생할 수 있습니다. 전기 용품 안전법은 UL 또는 CSA 인증 케이블 (코드에 UL / CSA 가 표시된 케이블)을 ALTos 가 지정한 제품 이외의 전기 장치에 사용하는 것을 금지합니다.

Stroomkabel en AC-Adapter

Waarschuwing! Bij het aansluiten van het Product uitsluitend gebruik maken van de geleverde Kabels of een andere geschikte aan te schaffen Aansluitmethode, deze moet altijd voldoen aan de lokale voorschriften en veiligheidsnormen, inclusief de juiste kabeldikte en stekker. Het gebruik van niet geschikte Kabels en/of Adapters kan een storing of brand veroorzaken. Wetgeving voor Elektrische apparatuur en Materiaalveiligheid verbied het gebruik van UL of CSA -gecertificeerde Kabels (met UL/CSA in de code) voor elke andere toepassing dan de door ALTos hiervoor beoogde Producten.

